



Table 2 IP Telephony Dial Plan

Pod	Dial Plan – Extension Numbers	Voicemail Extension	First E.164 DID number	Router FXS Port 0	Router FXS Port 1
Pod 1	5000-5029	5555028	5105555000	5555028	5555029
Pod 2	5030-5059	5555058	5105555030	5555058	5555059
Pod 3	5060-5089	5555088	5105555060	5555088	5555089
Pod 4	5100-5129	5555128	5105555100	5555128	5555129
Pod 5	5130-5159	5555158	5105555130	5555158	5555159